is home, making way for savings where it counts.

*Compared to a 72°F hold.



Pays for itself in under 2 years*

Keeps energy use low when no one





Thanks to our open API, ecobee3 lite seamlessly integrates with other home automation devices.

WORKS WITH









Contact ecobee for full integration list.

SUPPORT HOURS

8am-12am (Mon-Fri) and 9am-9pm (Sat-Sun) Toll Free: 1.877.932.6233 support@ecobee.com | ecobee.com







No recharging or power stealing. 5-year Pro install warranty.

PROtected

Get an extra 2 years of warranty when you professionally purchase and install your ecobee3 lite.

Company

Installed by



Control from anywhere

Customers can control their ecobee from anywhere with an iOS or Android device.

Heading home early?

Change your schedule remotely to ensure comfort when you arrive.

Extending your vacation?

Enjoy further savings by letting your ecobee3 lite know.

Learn more about what your thermostat can do at ecobee.com.


Helps manage hot or cold spots

Pairs with Room Sensors[™] to help with hot or cold spots throughout the home.

Room Sensors measure temperature to deliver comfort to the rooms that matter most. Sold separately.

At your convenience

Monitors heating and cooling systems and alerts customers if it senses something is wrong.









No recharging or power stealing. 5-year Pro install warranty.

5-YEAR PRO INSTALL WARRANTY

Get an extra 2 years of warranty when you professionally purchase and install your ecobee3 lite.



Here's why pros love us.

NO POWER-STEALING OR RECHARGING

No common wire? No problem. ecobee comes with a Power Extender Kit so it doesn't rely on other equipment to charge itself.

COMPATIBLE WITH MOST

Works with gas, oil, electric, and dual-fuel systems. Supports conventional (2H/2C) and heat pump (4H/2C) systems; humidifier, dehumidifier, ventilator, HRV, or ERV accessories. For full details, visit ecobee.com/compatibility.

EASY TO INSTALL

Everything you need comes in the box, plus direct access to support when needed.

Here's why consumers love us.

CONTROL FROM ANYWHERE

Customers can control their ecobee from anywhere with an iOS or Android device.

PAYS FOR ITSELF IN UNDER 2 YEARS*

Keeps energy use low when no one is home, making way for savings where it counts.

*Compared to a 72°F hold.

AT YOUR CONVENIENCE

Monitors heating and cooling systems and alerts customers if it senses something is wrong.

HELPS MANAGE HOT OR COLD SPOTS

Pairs with Room Sensors[™] to help with hot or cold spots throughout the home. Room Sensors measure temperature to deliver comfort to the rooms that matter most. Sold separately.



SUPPORT HOURS

Available 8am-12am (Mon-Fri) and 9am-9pm (Sat-Sun). 1.866.518.6740 | support@ecobee.com







TECH SPECS

COMPATIBILITY

Conventional (2H/2C)—Gas, oil, electric. Boiler (2-stage-heating).

Air-Cooled & Geo-Thermal Heat pumps (2 stage heat pump + 2 stage aux heat/2 cool) (4H/2C).

Dual-Fuel support.

WIRE TERMINALS

RC	O/B	W1
G	RH	W2
Y1	С	PEK
Y2		

POWERING METHOD

Wired 24VAC through terminals C or Rc. Power Extender Kit enables you to reliably power your thermostat without having to run a C wire.

POWER CONSUMPTION

Less than 3.5VA

CONNECTIVITY AND SECURITY

Wi-Fi, IEEE 802.11 b/g/n @ 2.4 GHz Wi-Fi Protected Access (WPA/WPA2) Wired Equivalent Privacy (WEP) DHCP (dynamic) or static IP addressing Transport Layer Security (TLS) 915MHz

BANDWIDTH

15-20 MB/month

SUSTAINABILITY

Mercury free
Arsenic free
PVC free

ROHS compliant

THERMOSTAT SENSORS

Temperature Proximity Humidity

ROOM SENSOR

Temperature Motion

TEMPERATURE RANGE

Temperature: 7° to 33°C (45° to 92°F)
Display: 5° to 37°C (40° to 100°F)
Sensitivity: +/- 0.5°C (+/- 1°F)
Operating: 0° to 55°C (32° to 130°F)

HUMIDITY RANGE

Display: 20% to 90% RH Sensitivity: +/- 5% RH

Operating: 5% to 95% RH (non condensing)

STORAGE

-35° to 45°C (-31° to 113°F) 5% to 95% RH (non condensing)

LANGUAGES

English

DISPLAY

3.5" full-color LCD touch screen320 x 480 pixel display

HOMEKIT-ENABLED

HomeKit requires an iPhone, iPad, or iPod touch with iOS 9 or later. Controlling HomeKit-enabled accessories away from home requires an Apple TV with tvOS 9.0 or later and an iPhone, iPad, or iPod touch with iOS 9 or later.

WARRANTY

5-year warranty (PRO Install only)

WHAT'S IN THE BOX

ecobee3 lite thermostat

Install guide
Backplate
Trim plate
Screws
Dry wall plugs
Wire labels
Power Extender Kit

PRODUCT DIMENSIONS

Thermostat

Length: 102.88 mm Width: 102.88 mm Depth: 21.4 mm

Trim Plate

Length: 170 mm Width: 170 mm Depth: 6.25 mm

Power Extender Kit Length: 62.1 mm Width: 60.1 mm Depth: 21.4 mm












How to use your ecobee3 lite.

Get to know your display screen.



Main menu

Adjust your schedule, settings, and more.

Quick Changes

Switch easily between Home and Away modes.

ecobee

How to use your ecobee3 lite.






A snowflake indicates your system is set to cool.



A flame indicates your system is set to heat.





How to adjust your Temperature Slider.

- 1. Tap the display screen to wake your thermostat.
- 2. Move the slider up to increase the temperature, move it down to decrease.

Note: Your set temperature will appear below the main temperature display.



How to see your weather forecast.

- 1. Tap the weather forecast icon.
- 2. Slide your finger up and down on the screen to scroll through the forecast.

How to adjust your comfort setting.

- 1. Open the ecobee mobile app.
- 2. Tap "Your thermostat" along the top left of the screen.
- 3. Tap the main menu at the bottom left of the screen.
- 4. Tap "Schedule".
- 5. Tap the "+" sign at the top right of the screen.
- 6. Select a temperature range for when you're home, away, or asleep.